



# Stand Alone Installation Tech Notice

## Spicy Curry Bosch



Affects: Spicy Curry Bosch

### ISSUE

We have received reports of incorrect wiring routing under the kickstand plate instead of above, preventing Stand Alone installation

### SOLUTION

The cables for the rear light and speed sensor will need to be rerouted before installation of the Stand Alone.

### INSTALLATION

**Step 1:**  
Remove rear wheel. Unscrew speed sensor from mounting boss using T10 Torx wrench. Cut the zip ties attaching the speed sensor wiring to frame.

**Step 2:**  
Unplug both wires from the bottom of the rear light by gently prying up the back of the plastic plugs with flathead screwdriver, as seen to the right. Remove plastic plug from end of wire by gently pulling.

**Step 3:**  
Using a flathead screwdriver, gently lift wiring guides on inside of rear fender and pull rear light wiring through. Repeat for all cable guides.

**Step 4:**  
Reroute wiring above kickstand plate as shown. Screw speed sensor back into place and secure wire to frame using zip ties. Re-feed rear light wire through fender guides. Insert wire ends back into plugs. Then insert plugs back into light. Install kickstand. Reinstall wheel.

#### STEP 1

*Remove wheel*



*Unscrew speed sensor*



#### STEP 2

*Remove plugs from light*



*Remove wires from plugs*



#### STEP 3

*Remove wire from fender guides*



#### STEP 4

*Reroute both wires on top of kickstand plate*

