

## Adapting Mundo V4 frame for Bread Basket with quick release mounting

Tools required:

- Hand drill
- Drill bit set

Step 1: Initial Preparation



Unscrew the quick release nut and remove small cam washer. Place large cam washer on the quick release skewer in the position shown above.

Step 2: Selecting the bit



Locate 6.5mm, or 1/4 in., drill bit. The bit should be slightly larger than the diameter of the quick release skewer.

### Step 3: Drilling out the threads



With the hand drill in the maximum torque or “drill” setting, drill out the threads in the Bread Basket mounting holes. Be sure that the bit is aligned both horizontally and vertically to the mounting hole during the start of the drilling. This process will take a few minutes if using a low powered drill.

Step 4a. Mounting the Bread Basket (If using new Bread Basket).



Mount the Bread Basket using the 8mm silver spacers (included with the original Bread Basket bolt attachment system) between the basket and frame in the configuration shown above. Hand tighten the quick release nut with the cam lever open, then close the cam lever to tighten the assembly.

Step 4b. Mounting the Bread Basket (if using old Bread Basket).



Mount Bread Basket using quick release, and hand tighten quick release bolt with the cam lever open, then close the lever to to tighten the assembly. Insure the basket attachment arms are making full contact with the frame, as seen above.