

1. Inspect area where spigots are being installed. If installing on a deck Is there sufficient blocking(4" blocking under decking material)? If going into concrete a 4" depth is recommended.
2. Layout spigots in desired locations. Typically evenly spaced (4' panel spigots would be placed 1' from edges of glass to give two foot spacing between spigots).
3. Verify spigots are spaced correctly and are inline. (snap chalk lines if necessary).attach Spigot to structure. Use 4"  $\frac{3}{8}$  lags for decks and 3  $\frac{1}{2}$ " long x  $\frac{3}{8}$  concrete anchor (chemical or wedge style.)
4. Verify spigots are level, shim if needed
5. Install foot covers
6. Install appropriate plastic shims and glass
7. Tighten and level glass by turning allen screws
8. Clean glass using an appropriate cleaner and enjoy the view.