



Alternate Tread Mounting Instructions

If your treads are not pre-drilled, use the following Alternate Tread Mounting instructions.

Pre-drill and Mount Treads

- Place your treads on the tread brackets.
 - Position the treads on the brackets so that their rise and run match the rise and run on your project drawing. If any adjustments are needed, follow the bracket adjustment steps on page 4 before mounting any treads.
 - Examine the treads, checking to see that they are centered on the stringer and sitting level on their brackets.
 - When all treads are in the correct position, drill 1/8" pilot holes 2" deep.
 - Using a T30 torx bit, install the tread mounting screws.
-