

Phone (209) 400-7200 Fax (209) 943-7923 www.wildhorses4x4.com

Intermittant Wiper Kit

#6326 Date 04/10/08

INSTRUCTIONS

- 1. Remove old stock wiper switch from dash. Using a bezel nut tool is recommended.
- 2. You will reuse the bezel and bezel nut from the stock switch. Test fit the bezel nut on the intermittent switch. Caution must be taken because it is easy to cross thread the switch and nut.
- 3. Remove the harness connector from the back of the old wiper switch.
- 4. Look at the harness connector drawing. You will need to remove the #4 wire from the connector. Push down the terminal retaining tab and pull the wire from the back of the harness connector. CAUTION: This wire is hot when your ignition switch is in the on or accessory position. Cut the terminal off and tape the wire back into the harness so that it is not loose.
- 5. Now remove the #3 wire in the same manner. Push the retaining tab back up and move this wire to the #4 position.
- 6. Plug the intermittent switch and black box into the under dash wiring.
- 7. You will notice that the intermittent switch control shaft is longer than the one on your old switch. If you want to you can use a dremel or something like it to cut the shaft to the stock length. Install intermittent switch into the dash using the old bezel and bezel nut. Also attach the ground wire from the intermittent switch to a good ground point under the dash.

