

CHEVROLET MOTORS CORP., MALDEN, MASS.

GRAPHIC ILLUSTRATION

ROOF TRIM PANELS - CAB

DATE  
8-15-66

MODEL  
R-11/11E BODY

DWG. - ORIGINAL  
CHK BY  
8-17-66  
ALAN JH 1/24/66

305

ITEM	PART NO.	DESCRIPTION	QUANTITY	
			R-11	R-11E
1	634280	PANEL-FRT	1	1
2	634281	PANEL-CENTER	1	1
3	634282	PANEL-REAR	1	1
4	646626	CLIP ASSEM.	4	4
5	620273	CLIP-ROOF TRIM RETAIN	10	10
6	640230	CLIP-SUN VISOR	2	2
7	6349065	MOLDING-FRONT	1	1
8	6349066	MOLDING-REAR	1	1
9	636427	CLIP-ROOF TRIM	14	14
10	642405	PANEL-FRT	1	1

ROOF TRIM PANEL INSTALLATION PROCEDURE

1. FASTEN SUN VISOR CLIPS TO ROOF AS ILLUSTRATED.
2. FASTEN ROOF TRIM RETAINER CLIPS TO ROOF AS SHOWN.
3. INSTALL REAR PANEL FIRST, SLIDING HARD BOARD UNDER CLIPS AS ILLUSTRATED.
4. INSTALL FRONT PANEL IN SIMILAR MANNER.
5. LOCATE CENTER PANEL AND SECURE WITH CLIP ASSEM.
6. SECURE ALL PANELS WITH FRT. END REAR ROOF TRIM MOLDING - LOCATE CLIPS AS ILLUSTRATED.

