



Important:

Install in accordance with RectorSeal® instructions as well as all applicable local plumbing, drainage and electrical codes.

EZ-TRAP® EZT105

Product Code 83105

Kit Contents

- (A) 3/4" Adaptor (1)
- (C) 3/4" Inlet Cross (1)
- (D) 3/4" Clear Deep U-Bend (1)
- (E) 3/4" Outlet Tee (1)
- (G) Red Drain Caps (3)
- Cleaning Brush (1)
- Red/Blue Service Label (1)
- Yellow Cleaning Label (1)

Trap Assembly Instructions

1. Screw Adaptor (A) into 3/4" primary drain pan outlet.
2. Dry fit, and mark components. Rotate U-Bend (D) and Outlet Tee (E) to required angles for installation.
3. Glue components (B thru E) using dry fit markings. Glue assembly into Adaptor (A). Assembly must be plumb.
4. Glue Drain Line (F) into center leg of Outlet Tee (E). Drain Line must exit building with at least a 5° angle.
5. Check that Red Drain Caps (G) are tightly secured.
6. Attach cleaning label as indicated.

Note: Insulation is required when trap is installed in unconditioned space where sweating can occur.