



QuickTrim™ Kits

Designed to fit Watco coarse-thread strainer bodies.
Two o-rings are provided.

U.S. Patent No. 7,503,083

INSTALLATION INSTRUCTIONS



Stretch an o-ring into the groove on the shaft of the **QuickTrim™**.



Press the **QuickTrim™** into the strainer body.

If it drops in loosely, remove the skinny o-ring and replace it with the fat o-ring. It should fit tightly when pressing it down into the strainer body.

If the fit is too tight, wet the o-ring and then press it into the strainer body.

For Assistance, call:

800-821-8576

Monday-Friday: 8:00 a.m.-4:30 p.m. CT

WATCO MANUFACTURING COMPANY

1220 South Powell Road • Independence, MO 64057-2724

Phone: 816-796-3900 • 800-821-8576 / Fax: 816-796-0875 • 800-399-2826

www.watcomfg.com

QuickTrim Inst. Rev. 6/09