

INSTALLATION INSTRUCTIONS

6" LED Dimmable Retrofit Down Light

WARNING - RISK OF ELECTRIC SHOCK. DISCONNECT MAIN POWER AT FUSE OR CIRCUIT BREAKER BEFORE INSTALLING OR SERVICING THE FIXTURE.

GENERAL: All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

INSTRUCTIONS

1. Compatible with cans sizes from 5" to 6".
2. Make sure the **light switch** is off. [Fig. 1]
3. Push the **switch** to the desired color temperature. [Fig. 2]
4. Thread the **socket adaptor** into the **socket**. [Fig. 3]
5. Plug the male connector of the **socket adaptor** to the **female connector** of the top of the **retrofit trim**. [Fig. 4]
6. Squeeze both torsion spring arms together and insert into the **torsion spring slots** (or **c-clips**) of the can. [Fig. 5]
7. Tuck all wires into the **can** and carefully push the **retrofit trim** into **can**. Make sure the fixture is securely flush against the ceiling surface.

