


Arnsberg

Das Licht

customerservice@arnsberg.com

www.arnsberg.com

MOUNTING INSTRUCTIONS



ASSEMBLY INSTRUCTIONS FOR

DESSAU TURBO/PIN UP KIT

225870108PUK/225870107PUK

NOTE: Wall Lamp Not Included

ASSEMBLY INSTRUCTIONS

- 1 Select desired wall location for scone installation. Using the mounting plate (B) as a template, mark the position of the four mounting screw holes. Drill the four holes and insert one plastic anchor (A) in each.
- 2 Place mounting plate (B) on wall, lining up mounting plate holes with the four holes you have drilled. Insert the self-tapping screws (C) into the holes and tighten until the mounting plate is secured to the wall.
- 3 Run the power cord (G) through a pre-drilled hole in the mounting plate (B) .
- 4 Fix the wire pole with a screwdriver in the wire connector (D) .
- 5 Line up the pre-drilled holes on the side of the back plate (F) with the pre-drilled holes on the mounting plate (B). Attach by inserting the three round head screws (I) and tighten it by screwdriver.
- 6 Choose a appropriate place below the bottom mounting plate. Drill two small holes on the wall according to the position of the holes located on the cord cover bracket place the three plastic anchors(I) in the drilled holes, attach the cord cover bracket(K) directly by using self-tapping screws (H).
- 7 Mount cord cover(J) by placing the top end just underneath the bottom of the back plate where the cord set come out.