
## **ASSEMBLY INSTRUCTIONS**









## **Barrett Medium Knurled Pendant**

Item # RL 5220

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. Thread the tube (F) to the tube (G).
- 3. Install the mounting plate (B) to the outlet box by mounting screws (C) provided.
- 4. Measure the wires and cut. Be certain to leave enough to connect inside of the canopy.
- 5. Connect the fixture ground (bare) wire with the ground wire from the outlet box using wire nut (A). If your house does not have ground wire, then attach this wire to the green grounding screw inside of the outlet box.
  - IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
- Connect the fixture Neutral wire (ribbed, no markings) with the neutral wire from the outlet box using wire nut (A).
- Connect the fixture Hot (smooth edge,markings) wire with the hot wire from the outlet box using wire nut (A).
  - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 8. Tuck these wire connections neatly into the outlet box to secure.
- 9. Put canopy (D) to the mounting plate (B) and secure with lock collar (E).
- Attach the rubber washer (I) and glass shade (K) to the metal plate (H) and secure with socket cup (J).
- 11. Insert bulb (not included) into the socket.
- 12. Installation is complete, turn on power at fuse or circuit breaker.



<sup>\*\*\*</sup>Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.