

Tel: +972-48-290-100

Fax: +972-48-325-251 www.compulab.co.il



Fitlet2 with 2 WLAN installation guide


- This guide is applicable for Fitlet2, configured with FC-PCI.
- It provides the installation instructions to add a 2nd WLAN module.
- Parts for installing this solution should be acquired from Compulab. Contact fitpcsales@compulab.co.il for more information
- For full instructions of the FC-PCI assembly with the fitlet2 please refer to the below link:


http://fit-pc.com/wiki/index.php/Fitlet2 FC-PCI installation instructions




Compulab















- 4. Plug the adapter to the mini PCIe port at the back of the FC-PCI, and fasten with the 2x Phillips screws.
- 5. Plug the IPX to SMA short antenna cables to the WiFi module.



- 6. Plug the FC-PCI to the M.2 connectors
- 7. Fasten the FACET with the Phillips screw





- 8. Assemble the SMA plugs to the supplied side panel.
- 9. Make sure that the top WiFi module's SMA antenna cables are routed correctly. Consult the FC-PCI installation guide





Tel: +972-48-290-100
Fax: +972-48-325-251
www.compulab.co.il





10. Complete by bringing both side panels to their designated location and assemble bottom cover with 4x Phillips chassis screws



