

BPT781 Installation

- 1) You will need to remove the rear seat, to remove the original package tray.
- 2) Once the rear seat and the original package tray are removed, remove your old speakers.
- 3) Reinstall the rear seat back temporarily.
- 4) Position the BPT781 in the car for test fit, it should fit snug around the rear seat back.
- 5) Once the package tray is in position you may need to trim the back edge and or the front edges that rest on the rear quarter interior side panels to achieve a perfect fit.
- 6) Once you have adjusted and trimmed to fit then proceed to mark from underneath from inside the trunk, the rear speaker hole locations on the package tray with a scribe or marker. This will aid in locating your new speaker holes in the package tray.
- 7) Remove the package tray from the car and cut the speaker holes in the package tray.
- 8) Reinstall the package tray and drop in your speakers to make sure that they clear the metal in your car if they do not you will need to trim the metal accordingly.
- 9) Once all of this is done you are ready to mount the package tray and install your speakers.
- 10) Make sure any wiring is out of the way before you mount it.
- 11) You will need to drill mounting holes in the package tray and the car's rear deck and then fasten the package tray to the car's metal structure with at least 4 screws.