

WHAT BOTTOM BRACKET DO I GET FOR MY NEW HAKKALUGI MX???

Well, what crankset do you want to fit?

Shimano Road cranks:

Use External 24mm BBs from (in alphabetical order):

Chris King, Part Threadfit T47 24X & Conversion Kit #8

Enduro Bearings, Part #s BKC-0741, BKS-0231

Praxis Works, Part # 47-3001

Wheels Manufacturing, Part # T47-OUT-SHIM-AC

White Industries, Part # BBE24T47

SRAM GXP 24/22mm stepped cranks:

Use 24/22mm External BBs from:

Chris King, Part Threadfit T47 24X & Conversion Kit #9

Enduro Bearings, Part #s BKC-0741, BKS-0231

Wheels Manufacturing, Part # T47-OUT-SRAM-AC

White Industries, Part # BBE22T47

BB30 road cranks, including SRAM cranks listed as "BB30/PF30"-compatible:

Use 30mm Internal BBs from:

Chris King, Part Threadfit T47 30I (no kit needed)

Enduro Bearings, Part #s BKC-0721, BKS-0201

Wheels Manufacturing, Part # T47-BB-30MM-AC

White Industries, Part # BBI306873T47

30mm road cranks from Easton, Rotor:

Use 30mm External BBs from:

Chris King, Part Threadfit T47 30X & Conversion Kit #27

Enduro Bearings, Part #s BKC-0731, BKS-0211

Wheels Manufacturing, Part # T47-OUT-30MM-AC

White Industries, Part # BBE30T47

BB386EVO road cranks, SRAM cranks listed as “BB30/386”-compatible:

Use 30mm External BBs

Chris King, Part Threadfit T47 30I (no conversion kit, use normal spacers)

Enduro Bearings, Part #s BKC-0731, BKS-0211

Wheels Manufacturing Part # T47-OUT-30MM-AC

White Industries, Part # BBE30T47 (not FSA cranks)

OR,

Use 30mm Internal BBs listed above AND

Use FSA adapter 200-3204 (BB386EVO cranks to BB30/PF30 BB). QBP part CR8502.

Campagnolo Ultra-Torque cranks:

Use BB cups from Enduro Bearings, Part “BB Cup Set T47 UT Ad”

Praxis M30 cranks:

Use BB from Praxis Works, Part #47-0000

Links:

<https://chrisking.com/search/products/t47>

<https://www.endurobearings.com/t47/>

<https://praxiscycles.com/>

<http://wheelsmfg.com/bottom-brackets/t47/t47-bottom-brackets.html>

<http://www.whiteind.com/t47/>



