

SPEEDIFORM

Installation Instructions for Quarter Window Louver (10-14All)



Step 1:

Using soap and water, thoroughly clean the quarter windows to remove any dirt. Allow the window time to dry. **Recommended: Use a clean lint free cloth and isopropyl alcohol, wipe down the window glass to remove any wax or grease. This will ensure the cleanest possible mounting surface.



Step 2:

Apply the supplied double sided tape to quarter window louver as shown above.



Step 3:

Before removing the tape backing, test fit the part on the vehicle to familiarize yourself with how it fits. Then remove the tape backing and install the part.



Step 4:

Apply firm even pressure to the tape surfaces to ensure proper adhesion.