

"Shower Curtain with Organizer Pockets"



Are bath time toys invading your shower? Here is a quick fix for a small space. Add decorative pockets to the inside of the shower curtain liner to help clear the clutter in the bath or shower!

Skill Level: Beginner

Created by: Kelly Laws, Marketing Project Manager

Supplies:

Baby Lock Grace Sewing Machine Baby Lock Teflon foot Purchased cloth shower curtain liner All-purpose thread to match ½ yard of decorative vinyl Spool of ¼" red dot ribbon Spool of ½" black dot ribbon Blue painters tape Washable fabric glue Eyelet punch Pins

Instructions:

1. Cut five pockets 8" x 9" from the decorative vinyl. We used this cute lady bug vinyl.



2. Use the eyelet punch to create 3 small holes 1" from the corner. This will allow water that may collect in the pockets to drain.



- 3. Fold the shower curtain liner in half and mark the center with a few pins.
- 4. Measure down approximately 12" from the top of the curtain and position the pockets on the inside of the shower curtain liner in a checker board fashion. Make sure to center the pockets with the center pinned line of the curtain. *Note: Raise and lower the pockets to be in the best location for your shower.*
- 5. Use the blue painter's tape to keep the pockets in place until they are secure with stitching. The painter's tape is designed to not leave a residue and it can be removed after the stitching is complete.
- 6. Thread the machine with all-purpose thread and attach the Teflon foot.



- 7. Stitch the vinyl pockets to the curtain using a straight stitch.
- 8. Cover the lower edge of the pockets with red dot ribbon. Straight stitch or glue to secure it in place.
- 9. Cover the side edges of the pockets with black dot ribbon. Straight stitch or glue to secure it in place.
- 10. Hang your shower curtain and fill the pockets!

For other exciting projects like this one, visit our Web site at www.babylock.com