

20|20

Gen3 20|20 FieldView Module Installation

The Gen3 20|20 FieldView Module is required for the Climate FieldView System to connect to the 20|20 display.

Step 1:

Connect the FieldView Module (FVM) to the DBM using the provided Ethernet cable



Step 2:

Connect the FVM to the iPad using the provided USB to lightning cable.

