

LIBERTY FURNITURE

ASSEMBLY INSTRUCTION

417-BR13/BR14/BR90 ITEM # 417-BR15/BR16/BR90

DESCRIPTION Panel Bed

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below.

PARTS LIST

Assembly steps:

Step 1. Assemble the Cross bar (G) to the Posts (L/R) (B) using Wood dowel (i), Bolt (e), spring washer (f), flat washer (g) and allen key (h). Step 2. Assemble the Posts (B) to the Headboard

(A) using Bolt (e), spring washer (f), flat washer (g) and allen key (h).

Step 3. Assemble the Side rails (D) to the Posts (B) and Footboard (C) using set-screw (a), washer (b), nut (c) and wrench (d).

Step 4. Attach the Slat support (F) to the Slat (E) Step 5. Screw slats (E) in place using screws (j).

NO. SKETCH **DESCRIPTION** Q'TY Headboard 1pc

В	<u> </u>	Post (L/R)		2pcs
С		Footboard		1pc
D		Side Rails		2pcs
Е		Slats	Queen	4pcs
			King	5pcs
F	€	Slat support	Queen	8pcs
			King	10pcs
G		Cross bar		1pc

HARDWARE LIST

NO.	SKETCH	HARDWARE		Q'TY
а	a 111111111111	5/16"x18x2-3/4"		8pcs
b	0			8pcs
С	S	5/16"		8pcs
d	S	12 mm		1pc
е	<u> </u>	5/16"x18x2"		6pcs
f	0	5/16"x12 mm		6pcs
g	0	5/16"x19 mm		6pcs
h		4 mm		1pc
i		Ø8x30 mm		4pcs
j	0 222222	#8x1"	Queen	8pcs
		#OX1	King	10pcs



