



20" SINGLE ROW LIGHT BAR BRACKETS

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

KIT CONTENTS

Dr and Pass Bracket (1 each)
Spacer (2)
1/20x 1.25 (2)
1/2 nut (2)
1/20Washer (4)
8mm x 35mm Bolts (2)

TOOLS NEEDED

3/4 Wrench
6mm Allen Wrench

INSTALLATION INSTRUCTIONS

1. Place brackets on mount as shown in **Photo 1**.
2. Using the provided 1/20bolts and nuts, using a 3/4 wrench secure the brackets to the mounting surface as shown.



PHOTO 1



PHOTO 2

2. Add light as shown and use the 8 x 35mm bolts with spacer shown in photo in **Photo 2 and 3**.



PHOTO 3



PHOTO 4

3. Using the provided allen wrench, tighten bolts up snug and check for proper lighting position. **See Photo 3.**
4. After achieving desired position, tighten bolts and recheck other installed hardware. **See Photo 4.**

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

Thank You for choosing Rough Country for your off road needs!!!