



20" SINGLE ROW LED HOOD MOUNT

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

TOOLS NEEDED

T50 Torx
6mm Allen Wrench

KIT CONTENTS

Hood Brackets (2)
Bracket Spacer Blocks (2)
Gaskets (2)
Button Head Bolts (4)
Socket Head Bolts (2)
LED Light spacers (2)

INSTALLATION INSTRUCTIONS

1. Using a T50 torx bit remove the two factory bolts on the passenger hood hinge. **See Photo 1.**
2. Place the gasket and spacer block onto the hood hinge. Make sure the gasket is between the spacer and hood hinge. **See Photo 2.**



3. Install hood bracket on top of the spacer and secure with the 8mm bolts as shown in **Photo 3**. Repeat on driver side.
4. Install the Led Light with the socket head bolts and led light spacers **See Photo 4**. Tighten with a 6mm allen wrench.



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

Thank You for choosing Rough Country for your off road needs!!!