



## Rear Corner Lights

### DODGE CHARGER



Item	Qty	Description
1	2	Corner Light – rear red
2	2	Foam sealer
3	4	4-40x1/2 SS Phillip
4	4	4-40 SS Nylock nut
5	4	#4 SS Flat Washer
6	4	7" wire ties
7	2	X-mas tree wire ties

1. Refer to official Chrysler procedure to remove and install OEM parts listed in this procedure.
2. Remove rear tail lights.
3. Remove rear fascia.
4. Remove trunk carpet
5. Locate grommet at rear LH of trunk and make an "X" shape cut. Use utility knife. Picture 1.
6. Locate 2 tail LED branches from the main harness P/N 82213019 in the LH side of the trunk and route them through the precut grommet. Picture 2.
7. Apply MOPAR Silicon Wind Shield & Glass Sealer around the grommet.
8. Place template Appendix A in position on the underside of rear fascia, drill (3) holes 1/8" diameter for LED installation mounting screws. Picture 3.
9. Use a hole saw 1" diameter to cut centre hole for LED's. Using a de-burring tool ensure edges are smooth.
10. Install the foam sealer (item 2) to back of LED lights.
11. Secure LED lights (items 1) to rear fascia using provided hardware (items 3, 4 & 5), the light with the longer cable goes on the passenger side.. Picture 4.



1.



2.



3.



4.

12. Route passenger side LED cable towards the driver side across the bumper and secure it to the OEM harness across the bumper using 4 wire ties (item 6) Picture 5.
13. Plug in both LED connectors to the main harness.
14. Secure excess wire above rear bumper beam on the driver side, use existent 2 holes and 2 x-mas tree wire ties (item 7). Picture 6.
15. Reinstall trunk carpet
16. Reinstall rear fascia.
17. Reinstall rear tail lights. Picture 7.



5.



6.



7.