Before beginning, use the second page of this instruction sheet to verify you have the correct sizes of 5-piece drawer heads.

Standard Drawer Heads

- Unpackage and remove slab drawer head from
- Place the slab drawer head face down and remove the drawer box front by removing the two screws on either side. (NOTE: Keep screws as they will be needed in Step 4)

False Front Drawer Heads

- Unpackage and remove existing face frame/ drawer head from box.
- Unscrew exisiting drawer head from face frame by loosening all four screws. (NOTE: Keep screws as they will be needed in Step 4)










False Front Drawer Head



- Place the 5-piece drawer head face down on a scratch resistant surface.
- Place the slab drawer head face down on top of the 5-piece drawer head so that exisiting screw holes are visible.
- Align all four sides of the 5-piece drawer head with slab drawer head.
- Keeping the sides algined, clamp the two heads together.





EP3

Using a 3/32" drill bit, drill through the existing slab drawer head and screw holes into the 5-piece drawer head.

DO NOT DRILL ALL THE WAY THROUGH THE NEW 5-PIECE DRAWER HEAD

 Place clear bumpers onto the 5-piece drawer head at all four corners.





lx

Standard Drawer Heads

• Align the holes in the drawer box front with the holes on the 5-piece drawer head that were drilled in Step 3.

 Attach the drawer box front to the 5-piece drawer front using the screws that were kept from Step 1

Assemble the drawer box following our normal assembly instructions.

False Front Drawer Heads

- Ensure there is a 1" space from the top of the face frame to the top of the new drawer head.
- Align the screw holes and attach the 5-piece drawer head to the face frame.





A 1" marking jig can be constructed using two pieces of scrap trim to assist in aligning the drawer heads

Prior to drilling any holes, it is important that your verify the correct 5-piece drawer head size. This chart will guide you in matching the cabinet with the correct drawer head size. Find your cabinet type in the first column and then verify the dimensions on the 5-piece box packaging.

Cabinet	Top Drawer	Middle Drawer	Bottom Drawer
B12	11.5 x 6.75		
B15	14.5 x 6.75		
B18	17.5 x 6.75		
B21	20.5 x 6.75		
B24-2	23.5 x 6.75		
B27	13.1875 x 6.75		
B30	14.6875 x 6.75		
B33	16.1875 x 6.75		
B36	17.6875 x 6.75		
B39	19.1875 x 6.75		
B42	20.5 x 6.75		
BB42	14.5 x 6.75		
BB48	20.5 x 6.75		
CC30	14.5 x 6.75	29.5 x 14.25	14.5 x 14
CSF42	23.5 x 6.75	27.0 X 14.20	14.0 X 14
DB12-3	11.5 x 6.75	11.5 x 10.5	11.5 x
DB15-3	14.5 x 6.75	14.5 x 10.5	10.5 14.5
DB18-3	17.5 x 6.75	17.5 x 10.5	x 10.5
DB24-3	23.5 x 6.75	23.5 x 10.5	17.5 x
DB30-3	29.5 x 6.75	29.5 x 10.5	10.5 23.5
DB36-3	35.5 x 6.75	35.5 x 10.5	x 10.5
DDB18	17.5 x 6.75	33.3 X 10.3	29.5 x
DWR1548	14.5 x 5.5		10.5 35.5
DWR1554	14.5 x 5.5		x 10.5
DWR1560	14.5 x 5.5		X 10.0
OC3384	32.5 x 6.75		
OC3390	32.5 x 6.75		
OC3396	32.5 x 6.75		
OCD337	32.5 x 6.75		
SB30	14.6875 x 6.75		
SB33	16.1875 x 6.75		
SB36	17.6875 x 6.75		
SB42	20.5 x 6.75		
SB48	23.5 x 6.75		
V24-2	23.5 x 6.75		
V27	13.1875 x 6.75		
V30	14.6875 x 6.75		
V33	16.1875 x 6.75		
V36	17.6875 x 6.75		
VB12	11.5 x 6.75		
VB15	14.5 x 6.75		
VB18	17.5 x 6.75		
VDB12	11.5 x 6.75	11 5 × 10 5	11 5
VDB15	14.5 x 6.75	11.5 x 10.5	11.5 x
VDB18	17.5 x 6.75	14.5 x 10.5	10.5 14.5
VSB36	15.25 x 6.75	17.5 x 10.5	x 10.5
VSB42	11.75 x 6.75	10 x 6.75	17.5 x
VSB48	11.75 x 6.75	17 x 6.75	10.5
		23 x 6.75	