

STYLE GUARD

BY



"IDEAS THAT WORK"

INSTRUCTIONS

K-20A

THIS STYLE GUARD IS SPECIFICALLY MADE FOR USE ON JAMBS WITH OFFSET HUNG DOORS.

INSTALLATION PREPARATION

Fit the OFFSET STYLE GUARD on the door to check if the gap between the door and jamb is sufficient to allow the door to close easily.

If the gap is not large enough, several measures can be taken to insure correct closure. You can cut away the weather stripping in the 8 inch area the STYLE GUARD will cover. Or you can adjust the pivots of the door over enough to allow the door to close easily.

If you are using the OFFSET STYLE GUARD with an Adams Rite full length bolt, saw the guard from the center cut to the appropriate lower cut, as determined by the handing of the door.

For accurate placement, place the STYLE GUARD on the jamb in the appropriate location. Next, close and lock the door to insure proper positioning. Then, mark or drill the holes while the door is still locked.

Use the pop rivets provided to secure the guard to the edge of the jamb. Drill a 5/16" hole all the way through the jamb and use the carriage bolts to complete the installation.

The Style Guard is available in the following models:

K-9A 4" Center Hung (Aluminum)
K-9B 4" Center Hung (Duranodic)
K-15A Double Door (Aluminum)
K-15B Double Door (Duranodic)

K-20A Offset Style (Aluminum)
K-20B Offset Style (Duranodic)
K-21A 4 1/2" Center Hung (Aluminum)
K-21B 4 1/2" Center Hung (Duranodic)

Keedex, Inc. • 510 Cameron Street • Placentia, CA 92870-6425
714-993-4300 • Fax: 714-993-4303

www.keedex.com • e-mail: info@keedex.com