







NOTES:

- 1. INSTALL STRIKE PLATE WITH #6 FLAT HEAD SCREW, USE 4X #6 PAN HEAD SCREWS TO SECURE LATCH
- 2. A STOP BLOCK OR DOOR STOP MUST BE USED. LOCATE .188" FORWARD OF LATCH, ADJUST LATCH LOCATION USING PROVIDED SLOTS.

How to specify

QTY	Series	Finish	Note
100	MTL23	US19	Magnetic touch latch, matte black finish

Code	Finish Description	
US19	Matte black anodized Alu	

BW23-009 03.2023

1 2 3 4 5 6