## Mounting Instructions: **DL-200** (LOCK ON **RIGHT** / **TOP MOUNTED**) $\frac{9}{32}$ minus GAP 13 minus GAP Conhō: GAP STEP 1 install latch RIGHT DOOR upward view from below OF CABINET $1\frac{13}{32}$ TOP OF CABINET STEP 2 install activator DRILL FOR #6 SCREW LATCH MECHANISM **ACTIVATOR** CENTERED ON DOORS Note: lock shown for reference but not included. Locks sold separately. OF CABINET TOP OF CABINET STEP 3 install catch (**a**) (**b**) CATCH **ACTIVATOR** LATCH MECHANISM CENTERED ON DOORS Note: lock shown for reference but not included. Locks sold separately.

OF CABINET

compx.com/instructions

Reorder #: INS-200 Copyright 2014 © CompX Security Products

## Mounting Instructions: **DL-200** (LOCK ON **LEFT** / **BOTTOM MOUNTED**) $\frac{9}{32}$ minus GAP Conhib: 13 minus GAP GAP STEP 1 install latch LEFT DOOR OF CABINET Note: lock shown for reference but not included. Locks sold separately. LATCH MECHANISM CENTERED ON DOORS **ACTIVATOR** STEP 2 DRILL FOR #6 SCREW install activator 13 32 BOTTOM OF CABINET OF CABINET Note: lock shown for reference but not included. Locks sold separately. LATCH MECHANISM CENTERED ON DOORS ACTIVATOR STEP 3 CATCH install catch BOTTOM OF CABINET OF CABINET Reorder #: INS-200 compx.com/instructions Copyright 2014 © CompX Security Products