




Installation Instructions:

1. Place the "Frame Side channel" (part with large screw holes) on the edge of the door stop centered with the lock. Mark the location of the screw holes and drill 1/8" pilot holes. Install using the long screws provided.
2. Place the "Door Side Channel" inside the "Frame Side Channel". Use a piece of foam to hold the two parts together in place or just hold in place with your hand.
3. Close the door and using a pencil mark the door at the top of the channel.
4. Open the door and place the "Door Side Channel" in place marking the screw locations. Drill 3/32" pilot holes and install using short screws.

TIP: Install each side using one screw and check that the parts line up properly and that the door closes properly before drilling and installing all the screws.

TIP: Ask your Security Consultant about key control- Who can and cannot receive duplicate keys as well as high security lock options.

Instrucciones de instalación:

1. Coloque el "canal de el marco" (parte con los agujeros mas grandes) en la orilla de donde topa la puerta y centrado con la cerradura. Marque la posición de los agujeros para los tornillos y taladre agujeros de 3mm. Instale los tornillos largos incluidos.
2. Coloque el "canal de la puerta" dentro de el "canal de el marco". Use un poco de goma espuma para detener las dos piezas juntas o deténgalas con su mano.
3. Cierre la puerta y usando un lápiz marque una línea de referencia arriba del canal.
4. Abra la puerta y vuelva a colocar el "canal de la puerta" en su lugar usando la línea de referencia y marque la posición de los agujeros. Taladre agujeros de 2.4mm e instale los agujeros cortos.

Recomendación: Instale los dos lados solamente usando un tornillo y verifique que las partes entrelacen correctamente antes de taladrar e instalar todos los tornillos.

Recomendación: Pregúntele a su consultor de seguridad acerca de el control de llaves Quien puede recibir o no duplicado de llaves y también acerca de opciones de cerraduras de alta protección.

Pro-Lok® And Entry Armor™ Are Trademarks Of Weinraub Enterprises, Inc. © 2012. www.ENTRYARMOR.com

Item # ELP-110-C



6 38246 31024 1



ELP-110-AL

UPC: 638246310227



ELP-110-B

UPC: 638246310234



ELP-110-C

UPC: 638246310241



ELP-110-DU

UPC: 638246310258