



1. Remove insert.
2. Trim to length required.
3. Fasten at location desired with screws provided.
4. Slide insert back into housing.
5. Crimp end to retain.