

### **ROLLER STOPS**



#### 271W Roller Bumper

Certification: Meets ANSI A156.16 for L02193

Base Diameter: 2" (51 mm)
Projection: 4-1/2" (114 mm)

Materials: Cast brass with grey rubber roller Finishes: US3, US10, US10B, US26, US26D

Fasteners: Three (3) #10 x 1" FPHWS and three (3) plastic anchors

Notes:

For use when two doors swing into each other at right angles (back to back)

Prevents damage to the door and door hardware





## 272W Roller Bumper

Certification: Meets ANSI A156.16 for L02193

Base Diameter: 2" (51 mm)r Projection: 6-1/4" (159 mm)

Materials: Cast brass with grey rubber roller Finishes: US3, US10, US10B, US26, US26D

Fasteners: Three (3) #10 x 1" FPHWS, and three (3) plastic anchors

Notes:

• For use when two doors swing into each other at right angles

(back to back)

· Prevents damage to the door and door hardware





#### 273W

# **Curved Roller Bumper**

Certification: Meets ANSI A156.16 for L12213

Projection: 2-21/32" (67 mm)

Materials: Cast brass with grey rubber roller
Finishes: US3, US4, US10, US10B, US26, US26D

Fasteners: Three (3) #10 x 1" FPHWS and three (3) plastic anchors Notes: • Used when two doors swing into each other at odd angles

· Prevents damage to the door and door hardware

