

idh

by St. Simons, Inc.
Quality Solid Brass Decorative Hardware & Bath Accessories

idhbrass.com

Installation Instructions for Storm/Screen Door Latch

Item# **21250**—with rosettes

Item# **21260**—with rectangular plates

Material: Solid Brass

Care: Clean with soft cloth and mild soap. Do not use harsh detergents. Lubricate with light oil.

Door Thickness: Min $\frac{7}{8}$ " Max $1\frac{1}{8}$ "

1. Drill $\frac{5}{8}$ " diameter spindle hole through door face. Ensure hole center is $1\frac{3}{4}$ " from the edge of the door.
2. Drill a $\frac{5}{8}$ " diameter latch hole. Ensure this hole is in the center of the door edge aligned with the spindle hole.
3. Insert the latch assembly
4. Insert the spindle by pushing the latch tongue in completely with the open side of the spindle facing away from the door edge.
5. Mount rosettes or plates plus lever and knob
6. To install strike, drill $\frac{3}{4}$ " diameter hole $\frac{1}{2}$ " deep in door jamb opposite center of latch. Depth of mortise is $1/16$ "+

