



**Installation Instructions:**

1. Insert the key and remove the Lock Body from the Ratchet Bar.
2. Slide the Ratchet Bar onto the inside sliding glass door and tighten screw snug but not too tight. Close both glass doors and the Ratchet Bar should be exposed on the outside of the door.
3. Slide the Lock Body onto the Ratchet Bar with the flat side towards the edge of the glass door.

**NOTE:**

The key is not required to slide the Lock Body down the Ratchet Bar to lock the doors. To unlock, insert and turn the key while sliding the Lock Body off of the Ratchet Bar.

**Instrucciones de Instalación:**

1. Introduzca la llave y remueva la cerradura de la barra de trinquete.
2. Deslice la barra de trinquete en la puerta corrediza de adentro y apriete el tornillo pero no mucho. Cierre ambas puertas y la barra de trinquete se debe de mirar por fuera.
3. Deslice la cerradura por dentro de la barra de trinquete con la parte plana hacia la orilla de la puerta de vidrio.

**Nota:**

No se necesita la llave para asegurar la cerradura. Para desatranca, gire la llave mientras desliza la cerradura hacia afuera.

Pro-Lok® And Entry Armor™ Are Trademarks Of Weinraub Enterprises, Inc. © 2009. [www.ENTRYARMOR.com](http://www.ENTRYARMOR.com)

Item # ELK-130-C



Need A Special Product? Visit Our Website For Custom Requests And New Product Additions.