




Installation Instructions:

1. Remove the cylinder from the door.
2. Install the adapter plate between the cylinder and the door.

Instrucciones de instalación:

1. Remueva el cilindro de la puerta.
2. Instale el adaptador entre el cilindro y la puerta.

Pro-Lok® And Entry Armor™ Are Trademarks Of Weinraub Enterprises, Inc. © 2009. www.ENTRYARMOR.com

Item # EAP-100-B



6 38246 31129 3

Need A Special Finish?
Visit Our Website For Custom Requests
And New Product Additions.