## STYLE GUARD

BY STATES

"IDEAS THAT WORK"

## K-15A DOUBLE DOOR STYLE GUARD

THIS STYLE GUARD IS SPECIFICALLY MADE FOR USE ON ALUMINUM DOUBLE DOORS.

## INSTALLATION INSTRUCTIONS

Fit the STYLE GUARD onto the door and check to see if the gap between the doors is sufficient to allow the door to close easily.

If the gap is not large enough, several measures can be taken to insure correct closure. You can cut away the weather stripping in the 8 inch area the STYLE GUARD will cover.

Or you can adjust the pivots of the door over enough, to allow the door to close easily.

The STYLE GUARD should fit snugly against the inactive door.

For accurate placement, place the STYLE GUARD on the inactive door in the appropriate location. Next, close and lock the door to insure proper positioning. Then, mark or drill the holes while the door is still locked.

Use the pop rivets provided to complete the installation. In the event that you need the Adams Rite punch out removed, secure the STYLE GUARD in a vise. Next, working from the backside of the STYLE GUARD, punch the bottom of the tab for best results.

The Style Guard is available in the following models:

K-9A 4" Center Hung (Aluminum) K-9B 4" Center Hung (Duranodic) K-15A Double Door (Aluminum) K-15B Double Door (Duranodic) K-20A Offset Style (Aluminum)
K-20B Offset Style (Duranodic)
K-21A 4 1/2"Center Hung (Aluminum)
K-21B 4 1/2"Center Hung (Duranodic)

Made in the U.S.A.

Keedex, Inc. • 510 Cameron St. • Placentia, CA 92870 714-993-4300 • Fax: 714-993-4303 www.keedex.com • e-mail: info@keedex.com