



K-6

**SOLID BRASS MACHINED
UNIVERSAL FOLLOWER AND
INSTANT MASTER PIN
REMOVAL TOOL**

DIRECTIONS

Follow plug using high rounded side of tool. When tool is completely inside cylinder, rotate tool 180° to low side. Then, move tool back and forth and rotate left and right until you are satisfied that all master pins have spilled out of cylinder. Rotate tool back to high side and follow plug back through.

For Almont padlocks, shackle side ball bearing must be removed to allow sufficient movement of follower.