

"IDEAS THAT WORK"

## K-17 SECURITY GUIDE AND BOLT

REPLACES
SLIDECO - W&F & BUILDERS BRASS WORKS



PLASTIC GUIDES AND PINS
MADE OF STEEL
CADMIUM PLATED
MADE IN THE U.S.A.



## INSTALLATION INSTRUCTIONS

- 1. Unscrew plastic pin and replace it with metal bolt.
- 2. By using the short side you replace the BBW guide.



By using the longer side you replace the Slide-Co and W&F plastic guides.

3. Select the mounting holes you are going to use and run the self-tapping screws through them once before mounting. Mount the guide onto the door.

Keedex, Inc. • 1051 N. Grove Street • Anaheim, CA 92806 714-630-0800 • Fax: 714-630-0801 www.keedex.com • e-mail: ask@keedex.com