

HIT-111

Our most versatile drill guide for retrofit jobs. The HIT-111 is a multipurpose jig used on both wooden or metal doors to retrofit cylindrical lever locks by Assa, Arrow, Corbin, Marks, Schlage, Russwin and many more. HIT-111 is your all-around tool for ADA mandated lever handle locks. Drill bushings on both sides of fixture to allow drilling from both sides of door. Fits 1-3/8" to 2" doors with standard 2-3/4" backset or 3-3/4" and 5" backset doors with the HIT-BAK. [See compatibility chart for complete list of locks covered.](#) (This tool replaces our old HIT-I and HIT-II drill guide.)



HIT-2

The HIT-2 is a multi-purpose nut driver for use on Schlage Rhodes, Schlage Rhodes Interchangeable Core, Assa Brooklyn, Arrow Sierra, Sargent LN, NT Falcon and Omnilock locks. The HIT-2 provides for better grip and control when tightening the spindle locking nut than does the plastic tool provided by the manufacturer, greatly decreasing installation time.



HIT-20

This multi-purpose nut driver is designed for Corbin/Russwin 800/CL3400 Series, Medeco Embassy, and Yale 5400L Series Grade 1 cylindrical lever locks. Why waste time with the throwaway drivers provided by manufacturers when you can do the job right-and faster with the HIT-20?



HIT-BAK

The HIT-BAK is an adapter kit usable with ALL the HIT series installation tools. Consisting of standoff bolts for both 3-3/4" and 5" backsets, the HIT-BAK provides for total on-the-job versatility.



HIT-15

For Sargent 10 Line, U.S. Lock, IDN and other Import Grade 2 Lever Locks

Accurately retro fit standard 2-1/8" crossbore holes with the thru-bolt holes required by the popular grade 2 lever handle locks sold by U.S. Lock and IDN Distributors. Will install other imported locks that use 5/16" diameter through bolts with a 2-5/8" center to center spacing. This unit through bolts to door using the existing 2-1/8" crossbore for alignment. All required mounting and function holes are located with hardened drill bushings on both sides of template to allow drilling from either side of door. See compatibility chart for complete list of locks covered. Standard drill guide will accommodate doors up to 2" thick, with a 2-3/4" backset. Locks with a 3-3/4" or 5" backset requires the optional HIT-BAK adapter.



HIT-12

For Best Cylindrical Lever Locks

If you install Best cylindrical lever locks, the HIT-12 is one installation tool you'll want. Mounting the HIT-12 to the door is a breeze, and drilling perfectly positioned holes is accomplished in a matter of minutes. Unit has bushings on both front and back plate to allow drilling from both sides of door. Fits 1-3/8" to 2" doors with a standard 2-3/4" backset or fits 3-3/4" and 5" doors with the HIT-BAK. See compatibility chart for complete list of locks covered.



HIT-13

For Sargent 6500 Series Grade 2 Locks

Designed to be used with Sargent 6500 series grade 2 locks as well as many imported and private labeled locks. Fits 1-3/8" to 2" doors with a standard 2-3/4" backset or 3-3/4", and 5" backset doors with the HIT-BAK. Unit has bushings on both front and back plate to allow drilling from both sides of door. See compatibility chart for complete list of locks covered.



HIT-101

For Unican 6000 Series Pushbutton Lock

Speed and precision make the HIT-101 a handy tool to aid today's locksmith. Installing Unican's 6000 series pushbutton lock is quick and easy using the existing 2-1/8" crossbore for alignment. All required holes are located with hardened drill bushings on both front and back plates to allow drilling from either side of door. Standard drill guide will accommodate doors up to 2" thick, with a 2-3/4" backset. Locks with a 3-3/4" or 5" backset requires the optional HIT-BAK adapter.

