

HIT-35

Router Template for Wood Jambs

The HIT-35 template system was designed to hold a multitude of router guides used to route openings in wood jambs. The HIT-35 can be mounted to the door jamb with a double headed nail system or the use of common dry wall screws. It can be centered on jamb thickness from 1-3/8" to 2-1/4". An adjustable slide system can be tightened for repeatability on like size jamb conditions. The HIT-35 is machined from bar aluminum and anodized gray.



HIT-35DB1

Router Template for Dust Box

Template for standard dust box used on dead bolt and T-strikes. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.

HIT-35DB5

Router Template for ASA Dust Box

Template for standard dust box used on ASA strikes. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.



HIT-35RP1

Router Template for Baldwin ASA Re-enforcing Plate

Template for the re-enforcing plate used under Baldwin's ASA mortise strike. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.



HIT-35SP1

Router Template for T-Strike Plate

Template for standard 1-1/8" wide x 2-3/4" tall T-strike. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.

HIT-35SP5

Router Template for ASA Strike Plate

Template for standard 1-1/4" wide x 4-7/8" tall ASA strike. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.



HIT-35SP7

Router Template for Kwikset Deadbolt Strike

Template for standard 1-1/4" wide x 3-5/8" tall Kwikset deadbolt strike. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.



HIT-35SP9

Router Template for Schlage "B" Lock Strike

Template for standard 1-1/8" wide x 2-3/4" tall Schlage deadbolt strike. Requires the use of a router equipped with a 5/8" od template guide and a 1/2" diameter router bit. The use of a plunge type router is recommended.

NOTE: This template attaches to and requires the HIT-35 template fixture for mounting to door jamb.