

Vinyl or Polyurethane Perimeter Seals

Installation Instructions

1. Cut seal to fit.
2. With door closed, position seal. Mark screw holes.
3. Drill pilot holes for screws using a 7/64" drill bit.
4. Install with screws provided in all mounting holes, working from one end to the other.
5. Adjust position so that gasket is slightly compressed against door but does not impede proper closing and latching.

**APPLICATION WARNING:
DO NOT DRILL THROUGH GASKETING MATERIAL.
DRILL BIT WILL DAMAGE MATERIAL.**

1. Corte el burlete o sello al tamaño requerido.
2. Con la puerta cerrada, coloque el burlete o sello en posición. Marque los agujeros para los tornillos.
3. Taladre los agujeros de guía para los tornillos usando una broca de 7/64".
4. Usando los tornillos suministrados, instale en todos los agujeros de montaje, trabajando desde un extremo al otro.
5. Ajuste la posición de modo que la junta esté levemente comprimida contra la puerta, pero no impida que se pueda cerrar y correr el pasador debidamente a la puerta.

**PRECAUCIÓN AL INSTALAR:
NO TALADRE A TRAVÉS DEL MATERIAL DE JUNTAS, YA QUE LA BROCA OCASIONARÁ
DAÑOS AL MATERIAL.**



POSITIVE PRESSURE TESTED GASKETING MATERIALS
FOR FIRE DOORS
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS
RATED UP TO 1-1/2 HOURS.
CATEGORY J