

National Guard Products Inc.

1-800-
647-7874




43CB

Cushion Bronze

43SB, 44SB, 45SB

Spring Bronze



Installation Instructions

Metal Frames

Use #41 drill for #4 wafer head drive nails install on 2" centers.

Wood Frames

Use #18 x 7/8" nails install on 2" centers.

1. Cut bronze to fit opening.
2. Install bronze on door frame header using fasteners for frame application shown above. Position flat edge of strip as close to stop as possible.
3. Install bronze on jambs of door frame. Miter top ends to prevent binding at corners.
4. Cut out material at lock strike. A #50SB lock strip can be purchased to seal this area if desired.
5. Adjust bronze so it does not impede proper closing and latching of the door.

3/13

