


National Guard Products Inc.

1-800-
647-7874



600, A605, B606, 672, 675 Astragal Seals



Installation Instructions

1. Remove brush from metal retainer.
2. Cut brush to length, using the cutting section of pliers or diagonal cutters. If bristles are not secure, use a drop of adhesive to secure the brush.
3. Cut the metal retainer to length.
4. Replace brush in metal retainer.
5. Position on door as shown above.
6. Mark screw holes.
7. Drill pilot holes with a 7/64" bit.
8. Install with screws provided.
9. Slightly peen the bottom end of each retainer in order to secure the brush from moving.
10. Adjust astragal so it does not impede proper closing and latching of the doors.



POSITIVE PRESSURE
TESTED GASKETING
MATERIALS FOR FIRE
DOORS. INTENDED FOR
APPLICATION TO STEEL TYPE
FIRE DOORS, RATED UP TO 3
HOURS AND WOOD TYPE FIRE
DOORS, RATED UP TO 1 1/2
HOURS.



GASKETING MATERIALS
FOR FIRE DOORS

10.13