


National Guard Products, Inc.

1-800-
647-7874

NGP

81369N Overhead Door Bottom Seal



Installation Instructions

1. Cut seal to fit.
2. Drill through neoprene using 3/16" drill bit at screw hole locations.
3. Locate material at bottom of door.
4. Mark screw holes.
5. Drill pilot holes for screws using 7/64" drill bit.
6. Install material with screws provided, working from one end to the other.
7. Adjust position so seal does not impede proper closing and locking of overhead door.