

# National Guard Products Inc.

1-800-  
647-7874



## Nylon Brush Perimeter Seals

### Installation Instructions

1. Remove brush from metal retainer.
2. Cut brush to fit opening, using the cutting section of pliers or diagonal cutters. If bristles are not secure, use a drop of adhesive to secure the brush.
3. Cut the metal retainer to length.
4. Replace brush in metal retainer.
5. With door closed, position seal and mark screw holes.
6. Drill pilot holes for screws with a 7/64" bit.
7. Install with screws provided.
8. Slightly peen the bottom end of each retainer to secure the brush from moving.
9. Adjust position so brush is touching against door, but does not impede proper closing and latching of door.



UL10C Positive Pressure  
Tested Gasketing  
Material for Fire Doors.

Also Classified in accordance with  
UBC 7-2 (1997).



UL10B  
Gasketing  
Material for Fire  
Doors.

Intended for Application to  
Classified Steel fire doors rated up  
to 3 hours and Wood type fire  
doors up to 1 1/2 hours except  
models: D620, E621, G622, H623,  
I624 up to 1 hour wood doors.

Smoke & Draft Control gasketing  
(Category H) meets requirements  
of UBC 7-2 (1997) part 2, NFPA  
105, IBC, and UL1784 intended for  
application to Classified 'S' label  
doors. Applies to the following  
models: 600, 602, A605, B606,  
A617, A625, A626, 670, 672, 675,  
676, 706E, 9000, 9600, 9605,  
9675, 9706E.