

97V Astragal



Installation Instructions

- 1. Cut astragal to fit.
- 2. Position astragal and mark screw holes.
- 3. Drill pilot holes for screws using a 7/64" drill bit.
- 4. Mount one piece of astragal on each leaf. The gasket material is tapered to allow smooth operation of either door. The overlap should be approximately 1/4".
- 5. Adjust position so astragal does not impede proper closing and latching of doors.

4/05