


C697, D698, **C699**



- C699
- 1. Remove bru from metal retainer. . Cut brush to fit opening, using the cutting section of pliers or diagonal cutters. If bristles are not secure, crimp the end of the metal
- or use a drop of adhesive to secure
 - the brush. 3. Cut the metal
- retainer to length. 4. Replace brush in metal retainer.
- With door closed position seal mark screw holes.
- Drill pilot holes for screws with a %4" bit. 7. Install with screws provided.
- 8. Slightly peen the ends of each retainer to secure the brush from noving. Adjust position so sweep does not impede proper closing and

latching of door. COM GP-RUSH

IEMPHIS Raines Roa is, TN 38118