

National Guard Products Inc.

1-800-
647-7874



Vinyl or Polyurethane Perimeter Seals

Installation Instructions

1. Cut seal to fit.
2. With door closed, position seal, Mark screw holes.
3. Drill pilot holes for screws using a 7/64" drill bit.
4. Install with screws provided in all mounting holes, working from one end to the other.
5. Adjust position so that gasket is slightly compressed against door but does not impede proper closing and latching.

APPLICATION WARNING:

DO NOT DRILL

THROUGH GASKETING MATERIAL, DRILL BIT WILL DAMAGE MATERIAL.

UL 10C Positive Pressure Tested
Gasketing Material for
Fire Doors. Also
Classified in accordance
with UBC 7-2 (1997).



UL10B Gasketing
Materials for Fire
Doors.

Intended for Application to
Classified Steel fire doors rated up
to 3 hours and Wood type fire doors
up to 1 1/2 hours.
4/07