

National Guard Products Inc.

1-800-
647-7874



Neoprene or Silicone Perimeter Seals

Installation Instructions

1. Cut seal to fit.
2. With door closed, position seal, Mark screw holes.
3. Drill pilot holes for screws using a 7/64" drill bit.
4. Install with screws provided in all mounting holes, working from one end to the other.
5. Adjust position so that gasket is slightly compressed against door but does not impede proper closing and latching.

APPLICATION WARNING:

**DO NOT DRILL
THROUGH GASKETING MATERIAL. DRILL BIT WILL DAMAGE
MATERIAL**



UL10C Positive Pressure
Tested Gasketing Material
for Fire Doors. Also
Classified in accordance
with UBC 7-2 (1997).



UL10B
Gasketing
Material for Fire
Doors.

Intended for Application to
Classified Steel fire doors rated up
to 3 hours and Wood type fire doors
up to 1 1/2 hours.

Smoke and Draft Control gasketing
(Category H) meets requirements of
UBC7-2(1997) part 2, NFPA 105,
IBC, UL1784, intended for applica-
tion to Classified 'S' label doors.

4/07