

National Guard Products Inc.



1-800-
647-7874

Nylon Brush Door Sweep

Installation Instructions

1. Remove brush from metal retainer.
2. Cut brush to fit opening, using the cutting section of pliers or diagonal cutters. If bristles are not secure, crimp the end of the metal or use a drop of adhesive to secure the brush.
3. Cut the metal retainer to length.
4. Replace brush in metal retainer.
5. With door closed, position sweep at bottom of door and tap down until contact is made between the sweep and the threshold. Mark screw holes.
6. Drill pilot holes for screws with a 7/64" bit.
7. Install with screws provided.
8. Slightly peen the ends of each retainer to secure the brush from moving.
9. Adjust position so sweep does not impede proper closing and latching of door.



UL10C Positive Pressure
Tested Gasketing
Material for Fire Doors.

Also Classified in accordance with
UBC 7-2 (1997).



UL10B
Gasketing
Material for Fire
Doors.

Intended for Application to
Classified Steel fire doors rated up
to 3 hours and Wood type fire
doors up to 1 1/2 hours

Smoke & Draft Control gasketing
(Category H) meets requirements
of UBC 7-2 (1997) part 2, NFPA
105, IBC, and UL1784 intended for
application to Classified 'S' label
doors.

7/08