Drill two 1/16" dia. holes from the inside



## Caution! Before you install:

If you use hollow rife al doors, determine whether the doors are reinforced enough to support the lock. If the door reinforcement is not adequate, consult the door manufacturer about proper reinforcement.

## Important! ' For deadbolt functions:

Extend the bolt before installing the core.

> Best Access Systems Indianapolis, Indiana

T56137/Rev A 1841409 ER7991-35 Feb 2002