



Peachtree Door Replacement Weather stripping Instructions

KIT CONTENTS

Weather stripping (WS.1)
Weather stripping kerf adaptor (WTSPKA.1)
Instruction sheet (38390350)

INSTRUCTIONS

Remove existing weather stripping from respective frame members and discard.
Position kerf adaptor over frame members and cut to fit.
Trim weather stripping similar.

With use of putty knife. Install adaptor into frame member as shown below.



Install weather stripping into kerf adaptor as shown at right

