

ASTRAGAL AND MEETING STILES

Applies to the following products:

29310_P, 29310_V

Testing/Ratings:





Category J gaskets for use with listed steel frames and/or classified steel covered composite, hollow metal doors rated up to and including 3 hours; wood and plastic covered composite doors rated up to and including 1-1/2 hours; and wood core doors rated for 20 minutes.

Tools Required:



Installation Instructions:

PERIMETER GASKETING:

- 1. Can be installed on a wood or metal frame.
- 2. Measure, mark and trim to length. Close door and position so that seal makes light even contact with door.
- 3. Drill pilot holes in stop at marks.
- 4. Secure with supplied screws.
- 5. Open and close door several times to check weatherstrip fit and seal.
- 6. To adjust, loosen screws, re-position weatherstrip, and tighten screws.
- 7. Snap on cover.

ASTRAGALS/MEETING STILES:

- 1. Trim lengths equal to door height.
- 2. Position at meeting stile edge of doors. Install screws in center of slots.
- 3. Adjust as required for proper seal, with ease of opening and closing, then tighten screws.
- 4. Snap on cover.