

Architectural Door Accessories

ASSA ABLOY

Pemko Perimeter Gasketing

The global leader in
door opening solutions

Applies to the following products:

29313_TF, 29321_TF

Installation Instructions:

1. Can be installed on a wood or metal frame.
2. Measure, mark and trim to length. Close door and position so that seal makes light even contact with door.
3. Drill pilot holes in stop at marks.
4. Secure with supplied screws.
5. Open and close door several times to check weatherstrip fit and seal.
6. To adjust, loosen screws, re-position weatherstrip, and tighten screws.
7. Snap on cover.


Testing/Ratings:

Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.
(Thresholds may or may not contain gasketing material).



BHMA
CERTIFIED

Tools Required:



www.pemko.com

MEMPHIS, TN USA	VENTURA, CA USA	VANCOUVER, BC CA	TORONTO, ON CA
P: 800 824-3018	P: 800 283-9988	P: 877 535-7888	P: 877 535-7888
F: 800 243-3656	F: 800 283-4050	F: 877 535-7444	F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

PG11_WEBINS
Rev 3 - 01.24.17
Page 1 of 1